

APPLICATION NOTE**Metasys Integrator® MGE UPS Systems Application**

Introduction	3
<i>Application Details</i>	3
<i>Component Requirements</i>	5
<i>Vendor Contact Information</i>	6
<i>Design Considerations</i>	7
Cable Connections	9
<i>Cable Pinouts</i>	9
<i>Connecting the Cable</i>	11
Metasys Integrator Setup	13
Point Mapping Tables	15
<i>Unitary, Parallel, and Static Switch Devices</i>	15
<i>Comet UPS Points</i>	19
Metasys Network Setup	22
<i>Mapping to a CS Object</i>	22
Custom Integration	24

Introduction

This document explains the Metasys Integrator® MGE UPS Systems application. Use this document with the Metasys Integrator technical bulletins in the *Metasys Connectivity Technical Manual (FAN 629.5)*, which provide information on installing and commissioning the Metasys Integrator unit. For information pertaining to MGE UPS Systems equipment, see applicable MGE UPS Systems documentation (obtainable from your MGE UPS service representative).

Application Details


The Metasys Integrator unit allows MGE UPS Systems equipment to become an integral part of the Metasys® and Metasys Companion™ Networks. Once an EPS-6000 or an EPS-3000/COMET is connected to Metasys or Companion Networks via the Metasys Integrator unit, their data is available to the full complement of Metasys Building Automation System (BAS) features, including Change-of-State (COS) monitoring, alarm notification, scheduling, trend, and totalization.

Up to 28 EPS-6000 or 255 EPS-3000/COMET devices can be connected to each vendor port of the Metasys Integrator unit, for a total of 56 EPS-6000 or 510 EPS-3000/COMET Uninterruptible Power Supplies (UPSs) on a two-port Metasys Integrator unit. Scan time may be unacceptable if the maximum number of devices is defined.

Figure 1 shows MGE UPS Systems and Metasys integration. Figure 2 shows MGE UPS Systems and Metasys Companion integration.


The Metasys Integrator unit supports the following MGE UPS Systems devices:

- EPS-6000 Unitary UPS
- EPS-6000 Parallel UPS
- EPS-6000 Static Switch Cabinet
- EPS-3000/COMET UPS



Note: If you use a UPM enclosure, you **must** install the Metasys Integrator 300 Series in a two high enclosure (EN-EWC25-0) rather than a one high enclosure (EN-EWC13-0) as shown in the figures in this application note.

Figure 1: MGE UPS Systems and Metasys Integration



Note: If you use a UPM enclosure, you **must** install the Metasys Integrator 300 Series in a two high enclosure (EN-EWC25-0) rather than a one high enclosure (EN-EWC13-0) as shown in the figures in this application note.

Figure 2: MGE UPS Systems and Metasys Companion Integration

**Component
Requirements**

To integrate MGE UPS Systems, you need the following:

- properly installed MGE UPS Systems with appropriate Communication Interface Option (RS-232 or RS-485)
- B&B RS-232 to RS-485 converter (485 TBLED) with power supply (if necessary)
- cables and connectors for connecting the converter to MGE UPS Systems
- Metasys Integrator unit
- N2 Bus (for connecting the Metasys Integrator unit to the Metasys or Companion Network)
- portable PC for downloading vendor communication tables (.VCT files) and network setup information, and for running diagnostics
- cable for connecting portable PC to the Metasys Integrator unit
- the correct vendor communication table (.VCT file) to download into the Metasys Integrator unit (supplied on CD-ROM)
- already installed communication trunk (RS-485) for the MGE UPS Systems equipment

This document describes the RS-232 cable and the vendor communication tables. MGE UPS Systems documentation describes their equipment. The remaining components are described in the Metasys Integrator technical bulletins.

**Metasys Release
Requirements**

To integrate MGE UPS Systems equipment into the Metasys Network, you need:

- Metasys OWS software Release 9.0 or higher
- Metasys Integrator software/firmware Release 9.0 or higher

**Metasys
Companion
Release
Requirements**

To integrate MGE UPS Systems equipment into the Metasys Companion Network, you need:

- Metasys Companion Release 7.0 or higher
- Metasys Integrator software/firmware Release 9.0 or higher

Vendor Component Requirements

Integration between the Metasys Integrator unit and MGE UPS Systems has been tested with the equipment listed in Table 1. Changes to this equipment or integration of MGE UPS Systems products not discussed in this document require additional software development and testing by Johnson Controls Systems Products. For information on integrating other products, refer to the *Custom Integration* section in this document.

Table 1: MGE UPS Systems Part and Software Version Numbers

MGE Product	Firmware Version
EPS-6000	PAJO Board, Rev. C1 and C3 Acq EPROM, Rev. G0 and H0 Com EPROM, Rev. J0
EPS-3000/COMET	PAJO Board, Rev. C0 Acq Firmware, Rev. B3 and B5

Vendor Contact Information

MGE UPS Systems, Inc.
1660 Scenic Avenue
Costa Mesa, CA 92626

Technical Support:
Phone: (800) 438-7373
FAX: (714) 434-7645
Internet: <http://www.mgeups.com>

B&B Electronics Manufacturing Company
707 Dayton Road
P.O. Box 1040
Ottawa, IL 61350

Phone: (815) 433-5100
FAX: (815) 433-5104

The following documentation is available from your MGE UPS Systems representative:

- All EPS-6000 products:
 - *GTC Link Communications Interface User Manual*
- All EPS-3000/COMET products:
 - *Comet J-BUS Communications System*

**Design
Considerations**

When integrating MGE UPS Systems equipment, consider the following:

- All MGE UPS Systems equipment must be set up and running properly **before** attempting to integrate with Metasys or Companion Networks. (The MGE UPS Systems representative is responsible for configuration of MGE UPS Systems equipment.)
- Make sure each UPS baud rate is set to 9600. (The MGE UPS Systems representative is responsible for setting the baud rate.)
- Each UPS must have a valid address and the address for each UPS is a unique communication address. Do not use Address 0.
- RS-232 cable distance between the Metasys Integrator unit and the RS-232 to RS-485 converter can be a maximum of 50 feet.
- Cable distance between the converter and the last UPS can be a maximum of 4000 feet.
- The appropriate communication option package must be present in UPS equipment. Verify the installation of this option with your local MGE UPS Systems representative.

Cable Connections

Cable Pinouts

When connecting to an RS-485 converter, use the following cable pinouts for the Metasys Integrator unit to the converter:




Figure 3: Metasys Integrator to Converter

EPS-3000/COMET Pinouts

Use the following pinouts for the EPS-3000/COMET:




Figure 4: Metasys Integrator to EPS-3000/COMET Using RS-232




Figure 5: Converter to EPS-3000/COMET Using Two Wires

**EPS-6000
Pinouts**

Use the following pinouts for the EPS-6000:




Figure 6: Metasys Integrator Unit to EPS-6000 Using RS-232




Figure 7: Converter to EPS-6000 Using Two Wires

Connecting the Cable

Connect the female end of the RS-232 cable to either Vendor Port A or Vendor Port B on the Metasys Integrator unit. Connect the other end to the RS-232 port on the MGE UPS Systems equipment or connect the other end to the RS-232 to RS-485 converter.




Figure 8: Port-to-Port Connection

Metasys Integrator Setup

To set up the Metasys Integrator unit, use a portable PC connected to Metasys Integrator Terminal Port. Metasys Integrator setup involves:

- downloading the correct vendor communication table (.VCT file)
- setting up the ports
- setting up the network addressing

It is necessary to download a .VCT file only once, even if more than one device is referencing the file.

The following table provides information specific to the MGE UPS Systems applications. For detailed procedures, see the Metasys Integrator technical bulletins.

Table 2: Metasys Integrator Setup for MGE UPS Systems

Vendor Communication Table (.VCT File)	
Unitary, Parallel, and Static Switch	MGEUPS.VCT
Comet	MGECOMET.VCT
Port Setup	
Baud Rate	9600
Word Length	8
Stop Bits	1
Parity	None
Interface	RS-232 or RS-485 (If using RS-485, refer to the <i>Cable Connections</i> section of this document.)
Network Setup	
Vendor Address	
EPS-6000	20, 28, 30 . . . F0, F8 (hex value only)
EPS-3000/COMET	1-FF (hex)
Timeout Value	1000 ms
Poll Delay	55 ms
Performance Guide	
Approximate Scan Time (For a single N2 address)	2 seconds

Point Mapping Tables

Unitary, Parallel, and Static Switch Devices

To get the hardware reference for mapping points to a CS object (via the software model), combine the NPT (Network Point Type) and NPA (Network Point Address). For example, the hardware reference for the Current Phase 3 Mains 1 point is AI3.

Table 3 shows the points available for mapping in the Unitary, Parallel, and Static Switch devices.

Table 3: Unitary, Parallel, and Static Switch Devices

NPT ¹	NPA ²	Unit	Description
AI	1	A	Current Phase 1 Mains ¹⁵
AI	2	A	Current Phase 2 Mains ¹⁵
AI	3	A	Current Phase 3 Mains ¹⁵
AI	4	A	Current Phase 1 Invert ⁵
AI	5	A	Current Phase 2 Invert ⁵
AI	6	A	Current Phase 3 Invert ⁵
AI	7	A	Current Phase 1 Mains ²⁴
AI	8	A	Current Phase 2 Mains ²⁴
AI	9	A	Current Phase 3 Mains ²⁴
AI	10	A	Current Phase 1 Load
AI	11	A	Current Phase 2 Load
AI	12	A	Current Phase 3 Load
AI	13	A	Current Battery (if battery is installed) ⁵
AI	14		% Load
AI	15		% Peak Load Phase 1
AI	16		% Peak Load Phase 2
AI	17		% Peak Load Phase 3
AI	18	V	U12 Volt Mains ¹⁴
AI	19	V	U23 Volt Mains ¹⁴
AI	20	V	U31 Volt Mains ¹⁴
AI	21	V	U1N Inverter Volt ⁵
AI	22	V	U2N Inverter Volt ⁵
AI	23	V	U3N Inverter Volt ⁵
AI	24	V	U12 Inverter Volt ⁵
AI	25	V	U23 Inverter Volt ⁵
AI	26	V	U31 Inverter Volt ⁵
AI	27	V	U1N Volt Main ²⁴
AI	28	V	U2N Volt Main ²⁴
AI	29	V	U3N Volt Mains ²⁴
AI	30	V	U12 Volt Mains ²⁴
AI	31	V	U23 Volt Mains ²⁴
AI	32	V	U31 Volt Mains ²⁴
AI	33	V	U1N Load Voltage
AI	34	V	U2N Load Voltage
1 Network Point Type			
2 Network Point Address			
4 Not available for Parallel UPS.			
5 Not available for Static Switch UPS.			

Continued on next page . . .

NPT ¹ (Cont.)	NPA ²	Unit	Description
AI	35	V	U3N Load Voltage
AI	36	V	U12 Load Voltage
AI	37	V	U23 Load Voltage
AI	38	V	U31 Load Voltage
AI	39	V	U Battery Voltage ⁵
AI	40	Hz	Frequency Mains 1 ⁵
AI	41	Hz	Frequency Inverter ⁵
AI	42	Hz	Frequency Mains 2 ⁴
AI	43	Hz	Frequency Load
AI	44	V	U Battery Voltage ⁵
AI	45	A	I Battery Current ⁵
AI	46	Min	Battery Backup Time (if installed) ⁵
AI	47	DegC	Battery Room Temperature Deg C ³ (if installed) ⁵
AI	48	DegF	Battery Room Temperature Deg F ³ (if installed) ⁵
AI	49	A	Current Rated Load
AI	50	kW	Power Rated Load
AI	51	kW	P1 (Load Active)
AI	52	kW	P2 (Load Active)
AI	53	kW	P3 (Load Active)
AI	54	kVA	S1 (Load Active)
AI	55	kVA	S2 (Load Active)
AI	56	kVA	S3 (Load Active)
AI	57	kW	P (Load Active)
AI	58	kVA	S1 (Load Apparent)
AI	59		% Inverter Load
AI	60		Power Factor
AI	61	DegF	Battery Room Temperature
<p>1 Network Point Type</p> <p>2 Network Point Address</p> <p>3 Duplicate points are shown in different units. This allows the Metasys Network to use either set of units.</p> <p>4 Not available for Parallel UPS.</p> <p>5 Not available for Static Switch UPS.</p>			
Continued on next page . . .			

NPT ¹ (Cont.)	NPA ²	Unit	Description
BI	1		Batt Circuit Brkr ⁵ 0-open 1-closed
BI	2		Batt Discharging ⁵ 0-no 1-yes
BI	3		Minimum Battery Volt ⁵ 0-no 1-yes
BI	4		Low Batt Shutdown ⁵ 0-no 1-yes
BI	5		Batt High Temperature ⁵ 0-normal 1-alarm
BI	6		Mains 1 Voltage ⁵ 0-normal 1-alarm
BI	7		Batt Room Ventilate ⁵ 0-normal 1-alarm
BI	8		Battery Charging ⁵ 0-no 1-yes
BI	9		Rect Charger Status ⁵ 0-off 1-on
BI	10		Major Rect-Chrg Fit ⁵ 0-normal 1-alarm
BI	11		Mains 1 Input Sw ⁵ 0-open 1-closed
BI	12		Emergency Off Sw ⁶ 0-inactive 1-active
BI	13		Rect-Chgr Input Volt ⁵ 0-normal 1-alarm
BI	14		Rect-Chgr Input Freq ⁵ 0-normal 1-alarm
BI	15		Grad Rect-Chgr Shut (if battery installed) ⁵ 0-inactive 1-active
BI	16		EngGenSet Curr Lim (if battery installed) ⁵ 0-inactive 1-active
BI	17		Batt Current Limit (if battery installed) ⁵ 0-inactive 1-active
BI	18		Battery Equalization (if battery installed) ⁵ 0-inactive 1-active
BI	19		Operation on Engine ⁵ 0-inactive 1-active
BI	20		System Normal 0-no 1-yes
BI	21		Unsafe Operation 0-safe 1-unsafe
BI	22		System Downgraded 0-no 1-yes
BI	23		Inverter Connected 0-no 1-yes
BI	24		Contactor K2S (only static switch > 800K) ⁶ 0-open 1-closed
BI	25		Mains 2 Input Switch ⁴ 0-open 1-closed
BI	26		Maintenance Bypass Sw ⁴ 0-open 1-closed
BI	27		Q5N Inverter Output Sw 0-open 1-closed
BI	28		Static Switch Status ⁴ 0-open 1-closed
BI	29		Battery Installed ⁵ 0-no 1-yes
BI	30		Battery Temperature Sensor Installed ⁵ 0-no 1-yes
BI	31		Inverter K3N Contactor 0-open 1-closed
ADI	1		Inverter Type @200 0-Unitary 1-Parallel without Static Switch 2-Parallel with Static Switch 3-Static Switch Cubicle
1 Network Point Type 2 Network Point Address 4 Not available for Parallel UPS. 5 Not available for Static Switch UPS. 6 Only available for Static Switch UPS.			

Comet UPS Points

To get the hardware reference for mapping points to a CS object (via the software model), combine the NPT (Network Point Type) and NPA (Network Point Address). For example, the hardware reference for the Current Phase 3 Mains 2 point is AI6.

Table 4: EPS-3000/Comet UPS

NPT ¹	NPA ²	Unit	Description
AI	1	A	Current Phase 1 Inverter
AI	2	A	Current Phase 2 Inverter
AI	3	A	Current Phase 3 Inverter
AI	4	A	Current Phase 1 Mains 2
AI	5	A	Current Phase 2 Mains 2
AI	6	A	Current Phase 3 Mains 2
AI	7	A	Current Phase 1 Load
AI	8	A	Current Phase 2 Load
AI	9	A	Current Phase 3 Load
AI	10	V	U Mains 1
AI	11	V	V1 Inverter
AI	12	V	V2 Inverter
AI	13	V	V3 Inverter
AI	14	V	U Mains 2
AI	15	V	V1 Load
AI	16	V	V2 Load
AI	17	V	V3 Load
AI	18	kVA	S Apparent Power
AI	19		% Load
AI	20		% Rated Load
AI	21	Hz	Frequency Inverter
AI	22	Hz	Frequency Mains 2
AI	23	Hz	Frequency Load
AI	24	#	Number of Times on Battery Power
AI	25	V	U Battery
AI	26	Min	Battery Backup Time
1 Network Point Type			
2 Network Point Address			
Continued on next page . . .			

NPT¹ (Cont.)	NPA²	Unit	Description
BI	1		Mains 1 Voltage 0-normal 1-alarm
BI	2		Chopper Operation 0-off 1-on
BI	3		Battery Circuit 0-normal 1-alarm
BI	4		End of Battery Time 0-no 1-yes
BI	5		Charger Status 0-normal 1-alarm
BI	6		Check Battery 0-normal 1-alarm
BI	7		Low Battery Shutdown Warning 0-normal 1-alarm
BI	8		Charger Operating Status 0-off 1-on
BI	9		Peak Overload 0-no 1-alarm
BI	10		Inverter Overload 0-no 1-alarm
BI	11		Inverter Operating Status 0-off 1-on
BI	12		Inverter Thermal Overload 0-normal 1-alarm
BI	13		K3N Contactor Status 0-open 1-closed
BI	14		Inverter Connected 0-no 1-yes
BI	15		Mains 2 Voltage 0-normal 1-alarm
BI	16		Mains 2 Frequency 0-normal 1-alarm
BI	17		Mains 2/Inverter Phase Shift 0-normal 1-alarm
BI	18		Phase Rotation 0-normal 1-alarm
BI	19		Mains 2 Overload 0-normal 1-alarm
BI	20		Mains 2 Thermal Overload 0-normal 1-alarm
BI	21		Normal 0-no 1-yes
BI	22		Danger 0-no 1-alarm
BI	23		Downgraded 0-no 1-alarm
BI	24		Low Battery Shutdown Warning 0-no 1-alarm
BI	25		End of Battery Time 0-no 1-yes
BI	26		Operating on Battery 0-no 1-yes
BI	27		Battery Valid Indicator 0-no 1-yes
1 Network Point Type			
2 Network Point Address			

Metasys Network Setup

Metasys Network setup is described in the Metasys Integrator technical bulletins. This section contains details specific to MGE UPS Systems applications.

Mapping to a CS Object

Table 5: Software Model and CS Object Definition

Application	Software Model (on <i>Tables and Models</i> CD-ROM)	Display Attribute (recommended)	NT Command Attribute (recommended)
Unitary	MGEUPS_U.DDL	AI1	AI1
Parallel	MGEUPS_P.DDL	AI1	AI1
Static Switch	MGEUPS_S.DDL	AI1	AI1
Comet	MGECOMET.DDL	AI1	AI1
* For the NT Command attribute, use the same attribute as the Display attribute. However, since the points are not commandable, you will not be able to command the attribute. (This must be defined because the NT Command attribute cannot be null.)			

Custom Integration

For information on integrating products that are not discussed in this document, first refer to the *Metasys Compatible Global Catalog*, an online list of released Connectivity products. If this list does not provide the information you require, consider using the *System Integration Project Data Sheet* to request a custom contract from the System Integration Team.

Both the *Metasys Compatible Global Catalog* and the *System Integration Project Data Sheet* can be accessed from *The Advisor* by performing the following steps:

1. Click on the Systems Products button located on the left side of *The Advisor* home page.
2. Click on the *Product Literature* link.
3. Click on the *Manuals-FANS* link.
4. Click on the *629.0 Metasys Connectivity Sales Resource Manual* link.
5. Find the *System Integration Project Data Sheet* link in the Table of Contents. Click on this link to view an online copy of the *System Integration Project Data Sheet*, or click on the *Metasys Compatible Global Catalog* link below it to view a list of released Connectivity products.

The *System Integration Project Data Sheet (LIT-6290052)* can also be found in the *Metasys Connectivity Sales Resource Manual (FAN 629)*.

If you need further assistance, contact the Johnson Controls Field Support Center.

Notes



Controls Group
507 E. Michigan Street
P.O. Box 423
Milwaukee, WI 53201

www.johnsoncontrols.com
FAN 629.5
Metasys Connectivity Technical Manual
Metasys Integrator Release 9.0
Printed in U.S.A.